

JENSON  
QT



Pod Kit  
User Manual

## **Specifications**

Battery capacity: 370mah

Pod capacity: 2ml

Coil resistance: 1.3Ω

Size: 80X37.5X10mm

Output:3.3V

Charging specification:5V/0.5A

## **Security Protections**

Low battery protection

Charging protection

Short circuit protection

Overuse protection

## **Lighting System**

1. When the battery life is between 51% to 100% the LED indicator will illuminate Green whilst inhaling. From 30% to 50% it will illuminate Blue. This denotes that you should consider charging your QT device. When the battery is under 30% the indicator will flash Red and stop working. You will need to recharge your QT.
2. When inserting the pod into the battery the LED indicator will flash once. When removing the pod the indicator will flash three times.
3. If the device detects a short circuit the LED indicator will flash five times.
4. Whilst charging:  
Lower than 70% - flashing Red light  
Over 70% - flashing Green light  
Fully charged - steady Green light
5. If you inhale for over ten seconds, the red light will flash 3 times and temporarily stop working.

# Refilling your QT Pod



1. Remove the plug from the top of the pod, open bottom silicone plug



2. Refill the juice with the needle bottle and let the pod sit 5-8min to make sure the wick is fully saturated



3. Press the silicone back tightly, insert the pod into the device and the battery light flash one time, start vaping



4. When you see the red light during a puff, please recharge the device



# CAUTION



1. Let the pod sit for 5-8 minutes to make sure the wick is fully saturated.
2. The pod should be replaced after refilling 5 times.



Jenson E-Cig



@jensonecig

[www.jensonecig.com](http://www.jensonecig.com)